



ACTIVITY CHAIR

Instructions

Maintenance:

- Before each use, make sure that all the parts are firmly secure and neither the desk nor the chairs are wobbly.
- Always wipe the product with a plain, dry cloth regularly and avoid using harsh chemicals.

Caution:

- The product must be assembled by an adult only. Keep all the parts out of the reach of kids until the product is fully assembled.
- Always place the product on an even surface. Using it on concrete or a rough surface can make it unsteady and may cause injuries.
- Packaging materials are not safe to play with and should be kept away from kids.
- Adult supervision is recommended when kids are using this product.

Warnings:

- Always assemble on a non-abrasive surface, ideally a carpet, to avoid scratches and make sure there are no sharp objects placed nearby.

Part Details



Chair Top Leg x 1



Chair Bottom Leg x 1



Chair Seat x 1



Backrest x 1



Instruction Manual x 1

List of Parts	No.
Chair Top Leg	1
Chair Bottom Leg	1
Chair Seat	1
Chair Backrest	1
Instruction Manual	1

Required Assembly Parts

1
STEP

Assembly Instructions



Chair Top Leg x 1




Chair Bottom Leg x 1




Chair Seat x 1

Before starting the assembly, lay out a carpet on the floor to avoid scratches.



Take a chair top leg and a chair bottom leg from the packaging. Position the top leg above the bottom leg making sure their grooves are aligned. Gently press down on the top leg to snap fit both the legs together.



Take the chair seat and align the grooves on its underside with the tabs on the chair legs as shown in the image. Firmly push the chair seat downwards, fitting the seat into place.

Model No: KDSAC

2+
YEARS



Scan to Connect

Before starting the assembly, please ensure that the part quantity matches the numbers listed in the manual. If you find any discrepancies in the part count or encounter any product-related issues, feel free to reach out to us at +918221001033 or connect with us via WhatsApp in between 9:30-6PM, Monday to Saturday. We're here to assist you!

DISCLAIMER: ACTUAL PRODUCT COLOR MAY VARY FROM THAT SHOWN IN THE IMAGE

2 STEP

Required Assembly Parts



Take the backrest and align the rectangular grooves on its back with the tabs at the top of the legs of the subassembly (step 1). Firmly push the backrest backwards to fit it into place.



Your Activity Chair is now ready for use!